

PLANET MUSIC®

POP BOXES 2007

THE SPECIALIST IN MUSIC
FOR MORE THAN 25 YEARS



Music Box
DP 545

Tambourine wood with head and 3 pairs
of jingles, pair of Maracas wood,
Castanet on handle wood,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 563

Glockenspiel with wooden base,
metal bars and mallet, Harmonica,
pair of Chicken Shake plastic
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 547

Glockenspiel with metal bars and mallet,
Tambourine wood with head and 3 pairs
of jingles, pair of Maracas wood,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box wood
DP 556

Glockenspiel wooden base with metal bars and
mallet, Tambourine with head and 4 pairs of
jingles, pair of Maracas wood, pair of Finger
Cymbals, wooden Stick with 13 Sleigh Bells,
14" x 10" x 1.5" 36 x 26 x 3 cm



Music Box wood
DP 555

Tambourine with head and 4 pairs of jingles,
pair of Maracas wood, Triangle chrome plated
with mallet, pair of Finger Cymbals, Wood
Block with mallet, wooden Castanet on handle
14 2/3" x 11 1/3" x 3" 37.5 x 28.5 x 8 cm



Wrist Bells
PM 104 - 3 - 36
3 bells on nylon strap, velcro,
length adjustable, 9" 23 cm,
for wrists or ankles.
Counter top display 36 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Chicken Shake Maracas
PM 274-36
5" 13 cm
Each color has a different sound.
The darker the color, the lower the pitch.
Counter top display 36 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Castanet on Handle
PM 148 - 20
handpainted,
DP 148 - C Cat 14 cm 5.5"
DP 148 - M Monkey 14.5 cm 6"
DP 148 - Z Zebra 17 cm 7"
DP 148 - P Panda 15 cm 6"
Counter top display 20 pieces
assorted designs
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Castanet Finger Type
PM 149 - 40
2 pcs for 2 hands, wood
handpainted
2.5" 6 cm
DP 149 - F Frog
DP 149 - L Ladybug
Counter top display 40 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Mini Sleigh Bells
PM 113 CL - 20
13 small bells colored,
on stick, 6 3/4" 17 cm
Counter top display 20 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm

Music Makes
Kids Smarter



Maracas
PM 283 - 10
wood, handpainted, 8" 20 cm
Counter top display 5 pairs / 10 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



The Original Ones.
Everything else is
just a copy.



Chicken Shakes
Display Boxes, assorted colors.
Each color has a different sound. Height 2" 5 cm.
The darker the color, the lower the pitch
DP 001- 024 Chicken Shakes display box 24 pcs
DP 001- 072 Chicken Shakes display box 72 pcs



Chicken Shake
DP 001 - 6C
plastic, 6 Chicken Shakes
assorted in colors in a carrying bag
7" x 4 2/3" x 2" 18 x 12 x 5 cm




Chicken Shakes
PM 001 - 45
counter top display 45 pieces,
assorted colors
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Handy Bells
PM 111-40
10 bells on a plastic handle,
diameter 3" 8 cm.
Counter top display 40 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm




Harmonica
PM 137 - 30
key of C, 16 holes, 16 double notes,
5" 13 cm
Counter top display 30 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Belly Bells
PM 110 - 10
10 bells on nylon strap, velcro,
length adjustable, 27" 70 cm
Counter top display 10 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Harmonica
PM 134 - 40
key of C, 10 holes, 20 notes,
4" 10 cm
Counter top display 30 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Ratchet
PM 972 - 25
wood, 2 tongues
small size, handpainted, 5" 13 cm
Counter top display 25 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Ratchet
PM 970 - 18
wood, 1 tongue, 5.5" 14 cm
Counter top display 18 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Kazoo
PM 139-50
counter top display 50 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm



Samba Whistle
PM 980 - 100
plays 3 different notes,
plastic, 2.5" x 2.5"
6 x 6 cm
Counter top display
100 pieces
9.5" x 8 2/3" x 4" 24 x 22 x 10 cm





Music Box
DP 542

Tambourine wood with head and 3 pairs of jingles, Jingle Stick wood, pair of Maracas wood,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 543

Tambourine wood with head and 3 pairs of jingles,
13 Sleigh Bellson wooden Stick, pair of Finger Cymbals chrome plated, Kazoo wood, Clapper wood,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 546

Tambourine wood with head and 3 pairs of jingles, Harmonica, pair of Finger Castanets wood, pair of Maracas wood,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 544

Tambourine wood with head and 3 pairs of jingles, pair of Maracas wood, Glockenspiel wood base with metal bars and mallet,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 564

Tambourine wood with head and 3 pairs of jingles, pair of Claves wood, Jingle Stick wood, Kazoo wood, Chicken Shake plastic
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 562

Maraca wood, pair of Finger Castanets plastic, 10 Sleigh Bells on handle, Chicken Shake plastic,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 548

Tambourine wood with head and 3 pairs of jingles, Glockenspiel wood base with metal bars and mallet, pair of Maracas wood, pair of Finger Cymbals chrome plated, 13 Sleigh Bells on a wooden stick, Castanet on handle wood,
15 2/3" x 13 1/3" x 2 2/3" 40 x 34 x 7 cm



Music Box
DP 561

Maraca wood, Castanets on Handle wood, 13 Sleigh Bells on wooden handle, Tambourine wood with 3 pairs of jingles,
11" x 8" x 2 1/3" 28 x 20 x 6 cm



Music Box
DP 560

Tambourine plastic with 4 pairs of jingles, Wrist Bells with 4 sleigh bells, Chicken Shake Maraca plastic, Kazoo plastic,
11" x 8" x 2 1/3" 28 x 20 x 6 cm

**Music Makes Kids Smarter
and sometimes adults too.**